




Scan 80 - Spare Parts



High Top, complete
51053138 (Black)
51053782 (White)




High Top for corner instal., complete
51053140 (Black)
51053783 (White)




Cover for top outlet
51053201 (Black)
51053785 (White)



Low top
51053200 (black)
51053781 (white)




Heat accumulation stones
51049926



Burn plate kit, complete
51053154




Connecting piece for tube outside
51053167




Screws for connecting piece
51053238

Gasket for flue outlet
51046849



Rear cover, complete
51053179 (Black)
51053787 (White)




Door, Complete
51053236

Inside cover for burnchamber kit
51053212



Cover for flue outlet
51046855



Vertical cover kit, left
51053160

Screw kit
51053327

Glass Gasket
AL
51053223

Top door list kit
51053183

Glass list, top or bottom
51053185


Door gasket (2,7 m.)
AM
51053187

Pin locking device
50006111


Bauart kit
51053157

Guide for baffle unit
51053210

Ash drawer
51053026




Secondary air handle
51053159



Primary air handle
51053158



Cast iron bottom
51053147



Gasket for cast iron bottom
51050570

Front glass kit
51053145

Vertical cover, Kit, Right
51053166

Closing mechanism kit
51053186

Pin
51053747

Shaft + Pin, kit
51053231

Pin locking device
50006111

Door handle, kit
51053216

Push out mechanism, kit
51053213


Bottom door list, kit
51053184

Glass list, top or Bottom
51053185


Door trim, left
51053234

Door trim, center
51053235

Closed base, complete
51053156 (Black)
51053784 (White)



Base with door, complete
51053155




Door for base
Incl. Hinges
51053237

Adjustment screws kit
M8x30
51046856



Small floor plate
Clear glass: 50052370
Smoked glass: 50052364



Large floor plate
Clear glass: 50052372
Smoked glass: 50052371

